

3 General Machine Data

3.1 Side denominations & identification plate

References in the text of this operating manual to the sides of the machine conform with the indications in fig. 3.1-1. The control panel (fig. 3.1-1) is located on the tending side (front side).




Fig. 3.1-1

- 1 Cup station
- 4 Dosing unit
- 7 sealing membrane station with point sealing
- 10 Sealing station
- 12 cellplate cleaning
- 13 Snap-on lid station
- 14 pneum. press-on station with tub-bottom ink printer
- 16 Lifting-out device and pusher